




Tool Connections / Anschlüsse


Inhalt

<u>Overview by connections / Übersicht nach Anschlüssen</u>	<u>2</u>
<u>Overview by devices/ Übersicht nach Geräten</u>	<u>3</u>
<u>Connections / Anschluss ZIP-USB-MP</u>	<u>6</u>
<u>Connection / Anschluss ZTH EU / ZTH-GEN</u>	<u>10</u>
<u>Direct connection / Direktanschluss MFT-C</u>	<u>13</u>
<u>MP-Bus Tester ZTH-EU</u>	<u>14</u>

Overview by connections
Übersicht nach Anschlüssen

Connection Anschluss	Matching Cable Passendes Kabel	MP level converters and devices MP-Pegelkonverter und Geräte	Page Seite
Service plug / Servicestecker 	ZK1-GEN 	 ZIP-USB-MP	6
		 ZTH EU / ZTH-GEN	10
Junction box / Anschlussdose 	ZK2-GEN 	 ZIP-USB-MP	6
		 ZTH EU / ZTH-GEN	10
		 MP-Bus Tester	14
Weidmüller Plug / Weidmüller Stecker 	ZK4-GEN 	 ZIP-USB-MP	8
		 ZTH EU / ZTH-GEN	11
		 MP-Bus Tester	14
RJ12 Socket / RJ12 Anschlussbuchse 	ZK6-GEN 	 ZIP-USB-MP	7
		 ZTH EU / ZTH-GEN	11
		 MP-Bus Tester	15
CR24 & NMV-D2M Socket / CR24 & NMV-D2M Anschlussbuchse 	ZK1-VAV 	 ZIP-USB-MP	9
		 ZTH EU / ZTH-GEN	12
Direct connection / Direktanschluss 	MFT-C 	 ZIP-USB-MP	13
		 ZTH EU / ZTH-GEN	13

Overview by devices /
Übersicht nach Geräte

 	ZK1-GEN 	Actuator / Antrieb 	10
	ZK2-GEN 	Junction box / Anschlussdose 	10
	ZK4-GEN 	VRP-M 	11
		BKN230-24MP 	11
	ZK6-GEN 	VRD3 	11
	ZK1-VAV 	NMV-D2-M 	12
		CR24 	12
	MFT-C  	Actuator / Antrieb 	13

Overview by devices /
Übersicht nach Geräte

Device Geräte	Cable Kabel	Connection Anschluss	Page Seite
	ZK1-GEN 	Actuator / Antrieb 	6
	ZK2-GEN 	Junction box / Anschlussdose 	6
		PC-Tool (MP-Master)	6
		MP-Bus Monitor	7
		MP-Bus Tester	14
	ZK6-GEN 	COU24A-MP 	7
		UK24MOD / UK24BAC 	8
	ZK4-GEN 	UK24LON / UK24EIB 	8
		VRP-M 	9
		BKN230-24MP 	9
	ZK1-VAV 	NMV-D2-M 	9
		CR24 	10
	MFT-C 	Actuator / NG-Antrieb 	13


Overview by devices /
Übersicht nach Geräten

Device Geräte	Cable Kabel	Connection Anschluss	Page Seite
MP-Bus Tester ZTH-EU 	ZK2-GEN 	MP-Bus	14
	ZK4-GEN 	VRP-M 	14
		BKN230-24-MP 	14
	ZK6-GEN 	UK24MOD / UK24BAC 	15

Connections / Anschluss ZIP-USB-MP


ZK1-GEN to actuator /Service socket

ZK1-GEN an Antrieb / Servicebuchse




ZK2-GEN to junction box

ZK2-GEN an Anschlussdose



ZK2-GEN to MP bus (PC-Tool as MP-Master)


ZK2-GEN an MP-Bus (PC-Tool als MP-Master)



Connections / Anschluss ZIP-USB-MP


ZK2-GEN to MP bus (monitor mode)

ZK2-GEN an MP-Bus (Monitor-Betrieb)



ZK6-GEN to COU24-A-MP


ZK6-GEN an COU24-A-MP



Connections / Anschluss ZIP-USB-MP


ZK6-GEN to UK24MOD / UK24BAC

ZK6-GEN an UK24MOD / UK24BAC



ZK4-GEN to UK24LON / UK24EIB


ZK4-GEN to UK24LON / UK24EIB



Connections / Anschluss ZIP-USB-MP


ZK4-GEN to VRP-M

ZK4-GEN to VRP-M




ZK4-GEN to BKN230-24MP

ZK4-GEN to BKN230-24MP



via ZK1-VAV to NMV-D2M


via ZK1-VAV an NMV-D2M



Connection / Anschluss ZTH EU / ZTH-GEN


via ZK1-VAV to CR24

via ZK1-VAV an CR24



via ZK1-GEN to NG actuator


via ZK1-GEN an NG Antrieb



*Connection ZTH-GEN similar to ZTH EU
Anschluss ZTH-GEN gleich wie ZTH EU

via ZK2-GEN to junction box


via ZK2-GEN an Anschlussdose



Connection / Anschluss ZTH EU / ZTH-GEN

via ZK4-GEN to VRP-M


via ZK4-GEN an VRP-M



*Connection ZTH-GEN similar to ZTH EU
Anschluss ZTH-GEN gleich wie ZTH EU


via ZK4-GEN to BKN230-24MP

via ZK4-GEN an BKN230-24MP



via ZK6-GEN to VRD3

via ZK6-GEN an VRD3




*Connection ZTH-GEN similar to ZTH EU
Anschluss ZTH-GEN gleich wie ZTH EU

Connection / Anschluss ZTH EU / ZTH-GEN

via ZK1-VAV to NMV-D2M


via ZK1-VAV an NMV-D2M



*Connection ZTH-GEN similar to ZTH EU
Anschluss ZTH-GEN gleich wie ZTH EU

via ZK1-VAV to CR24

via ZK1-VAV an CR24




*Connection ZTH-GEN similar to ZTH EU
Anschluss ZTH-GEN gleich wie ZTH EU

Direktanschluss / Direct connection MFT-C


Connection ZTH EU ZIP function

Anschluss ZTH EU ZIP Funktion



Connection ZIP-USB-MP


Anschluss ZIP-USB-MP



MP-Bus Tester (ZTH EU)


with ZK2-GEN

mit ZK2-GEN



with ZK4-GEN


mit ZK4-GEN




MP-Bus Tester (ZTH EU)

with ZK6-GEN

mit ZK6-GEN





All-inclusive.



-  5-year warranty
-  On site around the globe
-  A complete range of products from one source
-  Tested quality
-  Short delivery times
-  Comprehensive support

Headquarters

BELIMO Holding AG
 Brunnenbachstrasse 1
 CH-8340 Hinwil
 Tel. +41 43 843 61 11
 Fax +41 43 843 62 68
 info@belimo.ch
 www.belimo.com

Subsidiaries, Representatives and Agencies

Albania	Cameroon	Japan	Qatar
Algeria	Canada	Jordan	Romania
Argentina	Central America	Kazakhstan	Russia
Australia	Chile	Korea	Saudi Arabia
Austria	China	Kuwait	Serbia
Bahrain	Croatia	Latvia	Singapore
Belarus	Cyprus	Lebanon	Slovakia
Belgium	Czech Republic	Libya	Slovenia
Bosnia	Denmark	Lithuania	South Africa
Brazil	Egypt	Luxembourg	Spain
Bulgaria	Estonia	Macedonia	Sri Lanka
	Finland	Malaysia	Sweden
	France	Malta	Switzerland
	Georgia	Mexico	Taiwan
	Germany	Moldova	Thailand
	Greece	Montenegro	Tunisia
	Great Britain	Morocco	Turkey
	Hong Kong	Netherlands	United Arab Emirates
	Hungary	New Zealand	Ukraine
	Iceland	Norway	United States of America
	India	Oman	Vietnam
	Indonesia	Pakistan	
	Ireland	Philippines	
	Israel	Poland	
	Italy	Portugal	