

Characterised control valve, 3-way, Internal thread

- For closed cold and warm water systems
- For modulating water-side control of air handling units and heating systems
- Air bubble-tight (control path A AB)



Type overview							
Туре		kvs	DN	Rp	PN	n(gl)	Sv min.
]	m³/h]	[]	["]	[]	[]	[]
R3015-P25	-S1	0.25	15	1/2	16	3.2	50
R3015-P4-S	S1	0.4	15	1/2	16	3.2	50
R3015-P63	-S1	0.63	15	1/2	16	3.2	50
R3015-1-S1		1	15	1/2	16	3.2	50
R3015-1P6	-S1	1.6	15	1/2	16	3.2	50
R3015-2P5	-S1	2.5	15	1/2	16	3.2	50
R3015-4-S1		4	15	1/2	16	3.2	100
R3020-4-S2	2	4	20	3/4	16	3.2	100
R3020-6P3	-S2	6.3	20	3/4	16	3.2	100
R3025-6P3	-S2	6.3	25	1	16	3.2	100
R3025-10-S	S2	10	25	1	16	3.2	100
R3032-16-S	· -	16	32	1 1/4	16	3.2	100
R3040-16-S	· -	16	40	1 1/2	16	3.2	100
R3040-25-S	54	25	40	1 1/2	16	3.2	100
R3050-25-S		25	50	2	16	3.2	100
R3050-40-S		40	50	2	16	3.2	100
R3050-58-S	64	58	50	2	16	3.2	100

			20	00		-	0.2	100				
		R3050-40-S4	40	50	2	16	3.2	100				
		R3050-58-S4	58	50	2	16	3.2	100				
Technical data												
	Functional data	Media	Cold and warm water, water with glycol up to max. 50% vol.									
		Medium temperature -10120°C										
		Medium temperature note	dep can	The allowed media temperature can be limited, depending on the type of actuator. Limitations can be found in the respective data sheets of the actuators.								
		Rated pressure ps	160	0 kPa								
		Closing pressure Δps	140	0 kPa								
		Differential pressure Δpmax	350	kPa								
		Differential pressure note	200	kPa for I	ow-nois	se opera	tion					
		Flow rate Bypass B – AB: 70% of R										
		Flow characteristic	VDE	2178), (A – AB: equal percentage (VDI/ optimised in the opening range, AB: linear (VDI/VDE 2178)							
		Leakage rate	Con tight clas 12	trol path t (EN 122 s I (EN 1 2% of the	A - AB: Leakage rate A, air-bubble 266-1), Bypass B - AB: Leakage 1349 and EN 60534-4) approx. Exvs value, with respect to the Ewithin the DN							
		Pipe connectors	Inte	rnal threa	ad acco	ording to ISO 7-1						
		Angle of rotation	90° 15	- AB								
		Installation position	allation position Upright to horizontal (in relation to the stem									
		Maintenance	Mai	ntenance	-free							
	Materials	Housing	Brass body nickel-plated									
		Closing element	Stai	Stainless steel								



Technical data

Materials

Stem	Stainless steel
Stem seal	O-ring EPDM
Valve seat	PTFE, O-ring EPDM
Characterising disc	TEFZEL
	R3040-25-S4, R3050-40-S4, R3050-58-S4:
	Stainless steel

Safety notes



- The valve has been designed for use in stationary heating, ventilation and airconditioning systems and is not allowed to be used outside the specified field of application, especially in aircraft or in any other airborne means of transport.
- Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.
- The valve does not contain any parts that can be replaced or repaired by the user.
- The valve may not be disposed of as household refuse. All locally valid regulations and requirements must be observed.
- When determining the flow rate characteristic of controlled devices, the recognised directives must be observed.

Product features

Mode of operation

The characterised control valve is adjusted by a rotary actuator. The actuator is controlled by a commercially available modulating or 3-point control system and moves the ball of the valve – the throttling device – to the position dictated by the positioning signal. Open the characterised control valve counterclockwise and close it clockwise.

Flow characteristic

Equal percentage flow control is ensured by the integrated characterising disc.

Accessories


Mechanical accessories

Description	Туре
Pipe connector to ballvalves DN 15 Rp 1/2"	ZR2315
Pipe connector to ballvalves DN 20 Rp 3/4"	ZR2320
Pipe connector to ballvalves DN 25 Rp 1"	ZR2325
Pipe connector to ballvalves DN 32 Rp 1 1/4"	ZR2332
Pipe connector to ballvalves DN 40 Rp 1 1/2"	ZR2340
Pipe connector to ballvalves DN 50 Rp 2"	ZR2350

Installation notes

Recommended installation positions

The ball valve can be installed upright to horizontal. The ball valve may not be installed in a hanging position, i.e. with the stem pointing downwards.



Water quality requirements

The water quality requirements specified in VDI 2035 must be adhered to. Belimo valves are regulating devices. For the valves to function correctly in the long term, they must be kept free from particle debris (e.g. welding beads during installation work).

The installation of suitable strainer is recommended.



Installation notes

Maintenance


Ball valves and rotary actuators are maintenance-free.

Before any kind of service work is carried out on the actuator, it is essential to isolate the rotary actuator from the power supply (by unplugging the electrical cable). Any pumps in the part of the piping system concerned must also be switched off and the appropriate slide valves closed (allow everything to cool down first if necessary and reduce the system pressure to ambient pressure level).

The system must not be returned to service until the ball valve and the rotary actuator have been properly reassembled in accordance with the instructions and the pipeline has been refilled in the proper manner.


Flow direction

The direction of flow, specified by an arrow on the housing, is to be complied with, since otherwise the ball valve could become damaged. Please ensure that the ball is in the correct position (marking on the spindle).



Dimensions / Weight

Dimensional drawings



L1: Maximum screwing depth.

X/Y: Minimum distance with respect to the valve centre.

The actuator dimensions can be found on the respective actuator data sheet.



Dimensions / Weight									
Туре	DN []	Rp ["]	L [mm]	L1 [mm]	M [mm]	H [mm]	X [mm]	Y [mm]	Weight approx. [kg]
R3015-P25-S1	15	1/2	67	13	36	35	230	90	0.27
R3015-P4-S1	15	1/2	67	13	36	35	230	90	0.27
R3015-P63-S1	15	1/2	67	13	36	35	230	90	0.27
R3015-1-S1	15	1/2	67	13	36	35	230	90	0.27
R3015-1P6-S1	15	1/2	67	13	36	44	230	90	0.37
R3015-2P5-S1	15	1/2	67	13	36	44	230	90	0.37
R3015-4-S1	15	1/2	67	13	36	44	230	90	0.37
R3020-4-S2	20	3/4	78	14	41.5	46	235	90	0.46
R3020-6P3-S2	20	3/4	78	14	41.5	46	235	90	0.46
R3025-6P3-S2	25	1	87	16	45	46	235	90	0.65
R3025-10-S2	25	1	87	16	45	46	235	90	0.65
R3032-16-S3	32	1 1/4	105	19	55.5	50.5	240	90	0.95
R3040-16-S3	40	1 1/2	111	19	56	50.5	240	90	1.15
R3040-25-S4	40	1 1/2	122	19	66.5	62	250	90	1.15
R3050-25-S4	50	2	125	22	68	56	245	90	1.9
R3050-40-S4	50	2	142	22	79	68	262	90	1.8
R3050-58-S4	50	2	142	22	79	68	262	90	1.8

Further documentation

- · Overview Valve-actuator combinations
- · Data sheets for actuators
- · Installation instructions for actuators and/or ball valves
- General notes for project planning